

# BUILDTech

## CHEMICALS & SERVICES

### BuildTech Skim Coat-WR

**Product Description:** BuildTech Skim-Coat WR is a ready mix cementitious based skimming compound used for leveling of pin-holes, uneven plaster walls and ceilings, filling cracks and flattens the uneven surfaces to smooth-finishes, **BuildTech SK Putty** is highly recommended for direct use without primer.

#### Application:

- ✓ Applicable on Plaster Walls
- ✓ Ceilings
- ✓ Where moisture is remains on plaster surfaces
- ✓ Plaster Boards
- ✓ Gypsum Plasters

#### Advantages:

- ✓ Speedy Work
- ✓ Matt finish on 2 coat
- ✓ Smooth finish at 3 coat
- ✓ Good Pull off strength
- ✓ Cost-effective
- ✓ Almost zero-VOC
- ✓ Interior and exterior

#### Packaging:

**BuildTech SK Putty** is available in 5 and 15 kg sack

#### Storage:

**BuildTech SK Putty** shelf life is up to 6 months when stored in dry places and Temp. is in between 30-35 degree.

#### Curing Time:

Minimum 7 days are required to achieve the complete Product's properties in summer season (above 35 degree) and 10 days required for winter season.

#### Technical Data/ Properties:

Color	White- Mainly All colors on Demand
Coverage	20 Sqft per 1 Kg 2 coats
Layer Thickness Recom.	1-1.5 mm thickness
Pot life	45 Min at 25 degree
Open time	45 Min at 25 degree
Compressive Strength	> 7.5 Mpa in 28 days
Water Mixing Ratio	32-35 %

#### Method for Applicator:

**Substrate Preparation:** All the substrate surface should be clean from dust, oil, grease or any kind of loose materials.

**Mixing:** Suitable paddle or mechanically powder mixer should be used for proper mixing.

5-5.5 Liter water (Clean and fresh) is recommended for 15 Kg of pack of **BuildTech SK Putty**. Take 4 Liter in BuildTech Tub and add white powder slowly in the tub with slow speed electric paddle mixture add all powder during mixing add remaining recommended water in the Tub with proper safety precautions paste type constancy achieved. Leave the BuildTech SK putty paste for 5 mint. Check the consistency if required more water add it and mix it thoroughly.

#### Application:

- ✓ At the time of application, **BuildTech SK putty** should be free of lumps
- ✓ For better results, use full bag for mixing
- ✓ For ease of application and to save time use quality bigger putty blade.
- ✓ For better performance wet the surface.

**Cleaning:** Cleaning tools immediately.